


Operating, maintenance and repair  
instructions for

# MAXIMATOR<sup>®</sup> Compressors

## DLE 75



MAXIMATOR GmbH  
Walkenrieder Straße 15  
37449 Zorge

Phone: +49-55 86-80 30  
Fax: +49-55 86-8 03 40

E-Mail: [Info@maximator.de](mailto:Info@maximator.de)  
Homepage: [www.maximator.de](http://www.maximator.de)

# 1 Index

|       |  |    |
|-------|--|----|
| 1     | Index                                      | 2  |
| 2     | Mode of operation                          | 3  |
| 3     | Safety instructions                        | 4  |
| 3.1   | Usage to the intended purpose              | 4  |
| 3.2   | Emission                                   | 4  |
| 3.3   | Safety hazards                             | 4  |
| 3.4   | Safety at the place of assembly            | 5  |
| 4     | Technical data                             | 5  |
| 4.1   | Dimension drawing                          | 5  |
| 5     | Mounting                                   | 7  |
| 5.1   | Assembly                                   | 7  |
| 5.2   | Compressed air system                      | 7  |
| 5.2.1 | Compressed air quality                     | 7  |
| 5.2.2 | Compressed air oiler                       | 7  |
| 5.2.3 | Line cross-sections                        | 7  |
| 5.2.4 | Direct pilot valve air                     | 8  |
| 5.3   | High-pressure system                       | 8  |
| 5.3.1 | Inlet                                      | 8  |
| 5.3.2 | Pressure line                              | 8  |
| 5.3.3 | Pumping medium                             | 8  |
| 5.4   | Operation                                  | 8  |
| 6     | Maintenance                                | 9  |
| 7     | Warranty                                   | 9  |
| 8     | Repair                                     | 9  |
| 8.1   | High-pressure sealing repair               | 10 |
| 8.1.1 | Dismantling                                | 10 |
| 8.1.2 | HP piston assembly                         | 15 |
| 8.1.3 | Assembly                                   | 15 |
| 8.2   | Repair of air drive parts and pilot valves | 19 |
| 8.2.1 | Dismantling                                | 19 |
| 8.2.2 | Assembly                                   | 24 |
| 8.3   | Repair of suction and delivery valves      | 33 |
| 8.3.1 | Dismantling                                | 33 |
| 8.3.2 | Assembly                                   | 35 |
| 8.4   | Spool valve                                | 37 |
| 8.4.1 | Dismantling                                | 37 |
| 8.4.2 | Assembly                                   | 39 |

## 2 Mode of operation

As a rule, the MAXIMATOR compressors operate according to the pressure intensifier principle: large surface area with a low pressure (air piston(3)) → small surface area with a high pressure (HP piston(2)). A continual flow is attained by continuous pulsation. This pulsation is achieved by an impulse-controlled 4/2-way valve (servo-valve(4)). The servo-valve alternately impinges the top and bottom side of the air pistons. The servo-valve is selected via two 2/2-way valves (pilot valves(7)) that are mechanically by the air piston in its end positions. The pilot valves ventilate and vent the actuation chamber of the servo-valve. The drive air provides the restoring force for the servo-valve. In the actuation chamber the servo-valve has a larger effective surface area than in the control chamber that is permanently impinged with compressed air. The HP piston generates the volume flow by means of check valves (suction valve, delivery valve(1)). The HP section of the compressors consists of two stages. The first stage has a low pressure ratio and conveys directly into the second stage with a high pressure ratio. These two stages allow for the generation of a high operating pressure with sufficient compressor capacity, even with a low admission pressure. The initial pressure depends on the adjusted drive pressure. The below formula:

$$P_B = i_2 * P_L + \frac{i_2}{i_1} * P_A$$

where:


$P_B$  : Operating pressure

$P_L$  : Drive pressure

$P_A$  : Admission pressure

$i$  : Pressure ratio

is used to calculate the static final pressure. Upon reaching the final pressure the compressor stops and ceases to consume air. Only a pressure drop at the high-pressure side or a pressure increase at the drive side occasion the compressor to re-start.



### **3 Safety instructions**

MAXIMATOR compressors are manufactured to the latest state of the art and are safe to operate. However, there are potential hazards in case of inadvertent wrong operation or wrong use:

- For the health and lives of persons.
- For the compressor and its accessory parts as well as other assets.
- For the life cycle and the performance capacity of the compressors and its accessory parts.

Operation, maintenance and assembly of the compressor may only be carried by personnel who are familiar with working on pneumatic systems and are familiar with the hazards entailed by such systems. In addition, the operating instructions shall be thoroughly studied and adhered to.

#### **3.1 Usage to the intended purpose**

The compressors may be exclusively used with those media for which they are suitable according to our media endurance schedule. Any other media have to be tested by us for compatibility with the compressor materials prior to being used. The compressor drives are designed for compressed air up to 10 bar, other gases have to be tested by us for compatibility with the compressor materials prior to being used.

Changes and modifications of the compressors are prohibited for safety reasons.

All maintenance, assembly and operating instructions specified in these operating instructions must be adhered to in order to guarantee full functioning and safety.

#### **3.2 Emission**

Expanding compressed air is, depending on the specific application, prone to generate a certain level of noise. Moreover, exhausting air from the silencer may be fouled with water and oil (grease). It is also possible that small ice crystals form at the silencer, become loose and fly around. This is why persons have to wear goggles and, if need be, ear protection while in the vicinity of running compressors.

#### **3.3 Safety hazards**

During operation of the unit, both the drive part and the high-pressure part are under pressure. Hence, it should be borne in mind that any gas that may leak due to a defect or also during normal operation are highly pressurised and must not be contained or deviated by objects or body parts. It must be ensured that in case of a defect a compressor is immediately depressurised and repaired.

Maintenance and repair work may only be carried out at depressurised units.

### 3.4 Safety at the place of assembly

MAXIMATOR compressors must not be operated in closed containers, since the discharged drive air may burst the container.

The high-pressure bolted connections at the suction and pressure sockets must not be unscrewed, even if this would facilitate the erection of the compressor. The bolted connections must be firmly tightened in order to avoid any leakages and damage.

The air drive has been designed in such manner that the compressors are safe to be operated in areas that subject to explosion hazards.




The compressor should be installed in such a manner that the operating elements and bolted connections are freely accessible at any time.

## 4 Technical data

| Type   | Pressure ratio                    | Compression ratio | Admission pressure |      | Max. operating pressure | Turn-of-piston volume | Max. stroke frequency | Threaded connection |         | Max. operating temperature | Weight |
|--------|-----------------------------------|-------------------|--------------------|------|-------------------------|-----------------------|-----------------------|---------------------|---------|----------------------------|--------|
|        |                                   |                   | Min.               | Max. |                         |                       |                       | Inlet*              | Outlet* |                            |        |
|        | i                                 |                   | bar                |      | bar                     | cm <sup>3</sup>       | l/min                 |                     |         | °C                         | kg     |
|        | (i <sub>1</sub> /i <sub>2</sub> ) |                   | P <sub>A</sub>     |      | P <sub>B</sub>          |                       |                       |                     |         |                            |        |
| DLE 75 | 1:75                              | 1:20              | 35                 | 750  | 750                     | 25                    | 130                   | BSP 1/4             | BSP 1/4 | 100                        | 13     |

### 4.1 Dimension drawing

MAXIMATOR  
 Maßzeichnung / Dimension drawing  
 Typ / type: DLE 15, DLE 30, DLE 75



Antriebslufteinlaß....P<sub>1</sub> = G3/4 (3/4BSP)  
 (air drive inlet)  
 Gaseinlaß.....A = G1/4 (1/4BSP) >9/16-18UNF<  
 (gas inlet)  
 Gasauslaß.....B = G1/4 (1/4BSP) >9/16-18UNF<  
 (gas outlet)  
 Steuerluftanschluß....X = G1/8 (1/8BSP)  
 (external pilot con.)

|   |        |   |          |
|---|--------|---|----------|
| Bei allen den Vorrichtungen:<br>Anlagen- und Wartungsarbeiten nach DIN 100000.<br>Anlagen- und Wartungsarbeiten nach DIN 100000.<br>Sicherheitsvorschriften der Firmen- und Werke nach DIN 100000.<br>Anzeigen nach DIN 100000. |        | <b>MAXIMATOR</b><br>Schmidt, Kranz & Co GmbH<br>D-37449 Horge / Südhann |          |
| Modell:   | DLE 15 | Maßstab: 1:2  | Gewicht: |
| Druck:  | 16.00  | DLE 15(30, 75)  |          |
| Druck:  | 16.00  | MAXIMATOR - DLE   |          |
| Druck:  | 16.00  | doppeltwirkend / einstufig  |          |
| Druck:  | 16.00  | VP 16.00.48   | (3210.)  |
| Druck:  | 16.00  | VP 16.00.48   |          |
| Druck:  | 16.00  | VP 16.00.48   |          |

## 5 Mounting

### 5.1 Assembly

The mounting position of the compressor is optional. It must be ensured that there is no ingress of foreign matter into the connections of the compressor during assembly (e.g. boring dust during wall mounting). Hence, the blind plugs in the connections of the compressor should only be removed immediately before fastening the respective connections.

### 5.2 Compressed air system

We recommend the use of one of our air control units for compressed air supply. The units consist of a filter, water separator, shut-off valve, pressure controller, pressure gauge and, where appropriate, a safety valve. If there is no maintenance unit employed it must be ensured that the compressed air quality complies with our specifications.

#### 5.2.1 Compressed air quality

- Solid matter:
  - Max. particle size: 5µm
  - Max. particle concentration: 5mg/m<sup>3</sup>
- Dew point
  - + 10°C = water content 9.4g/m<sup>3</sup>
  - up to +2°C = water content 5.6g/m<sup>3</sup>

#### 5.2.2 Compressed air oiler

As a rule, a compressed air oiler is not required. All moving parts have been treated with special grease during assembly.

The grease may become gummy when the compressor is operated for a longer period of time with extremely dry air. It is recommended to replace the compressed air oiler in such a case.

**Caution!** If the compressor has been operated with a compressed air oiler it must not be later used without an oiler because the oil washes all grease out of the compressor and thus prevents permanent lubrication. The remedy is re-lubrication with MAXIMATOR grease.

If a compressed air oiler is used, the oil content of the air should be 1mg/m<sup>3</sup> to 5mg/m<sup>3</sup>.

#### 5.2.3 Line cross-sections

The air supply should not be dimensioned smaller than the threaded connection, a reduction to a smaller threaded connection may result in performance losses and malfunctions of the pump. Also excessively long supply lines may cause problems due to the pressure drop in a small line.

#### **5.2.4 Direct pilot valve air**

The compressors are designed for operation with direct pilot valve air which should be connected downstream of the pressure controller, if applicable. Thus, the pump can reverse better with small drive pressures. The compressor does not operate unless the direct pilot valve air is connected.

### **5.3 High-pressure system**

The employed HP piping and accessory parts must be matched in their pressure and cross-section to the compressor, otherwise the efficiency and safety of the compressor may be impaired.

#### **5.3.1 Inlet**

In order to achieve economic compressor output capacities and the indicated end pressures, the compressors have to be impinged with an admission pressure of the gas to be compressed. Only compressors with a pressure ratio of 2 can operate without admission pressure.

If there is no admission pressure available, an optimal compressor performance can only be realised with an underpressure-tight suction line. Otherwise the conveyed medium may be contaminated by ambient air. Cutting-ring bolted connections are not suitable.

A filter with a mesh width of max. 10µm should be installed into the suction line to avoid damage at the suction and delivery valves as well as at the HP sealing.

#### **5.3.2 Pressure line**

The pressure line and the respective accessories must withstand the max. initial pressure of the compressor. It is recommended to install an appropriate safety valve into the pressure line.

#### **5.3.3 Pumping medium**

The compressors shall be exclusively used with media that are suitable according to our media endurance schedule. Any other media have to be tested by us for compatibility with the compressor materials prior to being used.

### **5.4 Operation**

The compressor starts to deliver as soon as drive air as well as direct pilot valve air are available.

Escaping drive air is used in compressors with a higher pressure ratio to cool down the HP parts. However, when a compressor is running in continuous operation with a high stroke frequency, there may be considerable heating up of the compressor despite cooling. This may result in increased wear of the sealings. It is recommended to monitor the temperature of the compressed gas in order to avoid overheating. Temperatures above 100°C at the compressor outlet should be avoided.



## **6 Maintenance**

The air drives of all compressors have been pre-treated with heavy-duty grease and do not require any other type of lubrication. Only during overhauling of the compressor, the servo-valves and air pistons should be treated with acid- and silicon-free Maximator grease.

## **7 Warranty**

We grant a warranty for the material and manufacturing quality of our products of six months commencing upon the shipping date of the unit.

Defects that may be caused by inappropriate handling or malfunctions, the use of inadmissible liquids, foreign matter in drive or pumping media or be exceeding the max. operating pressure are not subject to warranty. Wearing parts, such as sealings, guide elements, etc., are exempted from our warranty.

## **8 Repair**

All repair work is to be carried out by qualified skilled personnel under extremely clean conditions. Even smallest impurification may cause serious damage at the precision-machined pneumatic components.

All individual pump and compressor parts are available from MAXIMATOR as spare parts. The respective purchase order numbers can be gathered from the drawings attached to each compressor. Typically, there is more than one sealing defective or worn out, hence, we have compiled different sealing kits. The compositions of sealing kits can be gathered from the drawings, like the respective purchase order numbers. Make sure to indicate the compressor serial number when ordering spare parts. The serial number is located in the machine plate of the compressor and is also punched into the compressor housing (as a 6-digit number).

It goes without saying that the most convenient approach for you is to ship a defective unit to us. All repairs are carried out by qualified persons in our workshops, where there are no metal-cutting activities and thus extreme cleanliness is ensured. As a rule we acknowledge the receipt of the forwarded unit and send you a cost estimate and, after your confirmation, repair your unit as quickly as possible and return it to you.

Note: Via our Homepage, you can access detailed repair instructions and drawings of the individual compressors that are to provide support to you during repair work or in case of any problems.

## 8.1 High-pressure sealing repair

### 8.1.1 Dismantling



Loosen the cooling pipe union nuts from pilot valve to cooling cylinder.




Loosen the four hexagon nuts from the stud bolts.



Carefully separate the compressor head by means of light taps with a plastic hammer from the HP cylinder.



Loosen the HP cylinder by means of light taps with a plastic hammer from the top cover.



Push the HP piston in the direction of the second stage until the stop point. Draw the HP cylinder from the HP piston until it levels with the former.



Move the O ring and the securing sleeve along the piston rod until the boring for the dowel pin is free.




Use a suitable mandrel to drive the dowel pin Item 16 out of the boring.

Pull the HP piston out of the HP cylinder.






Remove the retaining pin.



Carefully loosen the castle nut. Caution:  
Tightened package expands due to spring pre-  
tensions.

Now the HP sealing unit can be easily removed from the HP piston.



Dismantle the two back-up rings and the O ring from the HP head.



Remove the O ring that seals the cooling cylinder.



Dismantle the O rings that seal the cooling cylinder and the HP cylinder.



### 8.1.2 HP piston assembly

Clean all re-used components and inspect them for any damage.

Slightly grease all sealing and guide elements.

Use preferably MAXIMATOR grease Works No. 3610.1456.

Grease the O rings that seal the top and bottom covers of the HP and cooling cylinders.



### 8.1.3 Assembly

Put the following on the guiding piston in the indicated sequence: Supporting ring, sealing washer, supporting disk, piston packing, O ring (well greased), tightening element, guiding disk, pressure spring and guiding ring.





Now screw the round nut with hole onto the centring piston. Compress the complete sealing package in anti-spring force direction until the two borings (round nut with hole and centring piston) are aligned.

Secure the bolted union with a retaining pin. Afterwards, adjust the retaining pin in such manner that it does not project beyond the diameter of the centring piston (see Fig. below).









Insert the complete sub-assembly into the pressure cylinder.  
 Caution: For this operation, place the pressure cylinder on a workbench with the large 45° chamfer facing downwards. Insert the sub-assembly HP piston with the castle nut facing upwards (visible) into the cylinder until the O-ring is barely visible. Check the correct seat of the O ring and, if need be, bed the ring carefully between tightening element and piston sealing ring. Only then push the HP piston into the pressure cylinder until it is flush.  
 Caution: Make sure not to damage the O ring in the process.



Move the pressure piston to the other side of the pressure cylinder so that the through boring of the centring piston is fully visible.



Mount the O ring and securing sleeve to the piston rod.



Attach the dowel pin and insert the centring piston into the boring at the piston rod, then beat in the dowel pin.



Push the securing sleeve over the securing pin and safeguard it with the O ring.



## 8.2 Repair of air drive parts and pilot valves

The HP parts have to be dismantled before the air drive parts can be disassembled.

### 8.2.1 Dismantling

#### 8.2.1.1 Dismantling of the air drive

Remove the servo-valve and the air pipe, loosen the 4 socket head screws.



Remove the four hexagon nuts from the hexagon bolts.


Draw the bottom cover from the air cylinder. Now also the pressure pipe can be dismantled.  
Caution: The piston rod must not be withdrawn from the top cover because it may get jammed in the end groove.





Withdraw the air cylinder from the top cover and the air piston.

Pull the air piston slightly out of the top cover and remove the retaining pin and bolts.



Pull the piston rod out of the top cover into the direction of the HP part.



Remove the O ring from the air piston.



### 8.2.1.2 Dismantling of top cover and bottom cover



Remove the locking ring.

Knock the bearing bush out of the top and bottom covers by means of a plastic mandrel.



Remove the O rings from the bearing bush.

Remove the sliding rings and O rings from the bearing bush.





Dismantle the O ring that seals the air cylinder.



Dismantle the O rings for the control pipe from the top and bottom covers.



Remove the O rings from the pressure pipe.

Loosen completely and unscrew the pilot valve screw.





Withdraw the USIT ring, compression spring and pilot valve tappet.

Turn the top cover round in order to lever out the serrated ring, washer and O ring by means of a small screwdriver. The components are destroyed in the process.



## 8.2.2 Assembly

### 8.2.2.1 Assembly of the top and bottom covers

|  |  |
|--|--|
|  <p>Wedging mandrel</p> <p>Centring mandrel</p> | <p>The following tools are necessary to re-assemble the pilot valves: A centring mandrel, Works No. 3610.0284, and a wedging mandrel Works No. 3610.0285</p>   |
|    | <p>Slip the serrated ring, washer and O ring in this order onto the centring mandrel. When attaching the serrated ring, make sure that the serration points away from the O ring.</p>  |
|   | <p>To begin with, insert the centring mandrel into the tappet boring. Then drive the entire package with some hammer strokes into the boring.</p> <p>Caution: Make sure that the O ring is fully attached to the bottom.</p> |



Grease and re-insert the pilot valve tappet. During assembly a tangible resistance must be felt from the previously mounted O ring.



Slip the compression spring onto the pilot valve tappet.

Insert the USIT ring into the boring. Then tighten the pilot valve screw with a torque of 25Nm.



Now turn the top cover round. Then use the wedging mandrel to safeguard the serrated ring against slipping out. Upset the boring with a few hammer strokes.



Insert the O ring into the bearing bush.



Form the sliding ring into a kidney shape and insert it. Subsequently, bring the sliding ring inside the groove back into its original form. Caution: Do not bend the sliding ring too sharply.





Then mount the two O rings into the grooves at the external diameter of the bushing.

Grease the boring in the cover and insert the bushing with pressure.  
Caution: Make sure not to inadvertently remove the O rings



Insert the locking ring into the foreseen groove. Check also for its correct seat.



Mount the O ring that seals the air cylinder.

### 8.2.2.2 Air drive assembly




Grease the bearing bush of the bottom cover.



Insert the air piston with piston rod into the bottom cover.

Grease and attach the O ring for the air piston.



Grease the air cylinder.

Attach the air cylinder onto the air piston, carefully insert the O ring into the cylinder while doing so. Push the air cylinder and the bottom cover together until the air cylinder fits closely to the bottom cover.







Carefully move the piston rod from outside through the greased bearing bush of the top cover. Caution: Make sure not to damage the sliding rings in the bearing bush in the process.








Insert the piston rod into the piston rod holder of the air pistons and fasten with the pin.





|   |   |
|---|---|
|    | <p>Safeguard the sub-assembly with the retaining pin.</p>   |
| <p>Place the O rings for the capillary control tube into the top and bottom covers and use the capillary control tube to push the O ring into the boring till to the stopper.</p> |   |
|   |                      |
|    | <p>Slightly push the top and bottom cover together and insert the capillary control tube.</p>           |
|    | <p>Carefully push the air drive part together until the air cylinder fits closely to the top cover.</p> |

|   |   |
|---|---|
|    | <p>Attach washers and fastening brackets to the hexagon bolts and mount these assemblies. Caution: The hexagon bolt (longer design) is placed at the air supply side, marked with PL.</p> |
|    | <p>Also on the opposite side, the fastening brackets, screw retainers and washers are pre-assembled together with the hexagon nuts.</p>   |
|   | <p>Tighten the bolts only slightly.</p>   |
|  | <p>The DLE is placed on a workbench for alignment and a soft hammer is used to align the top and bottom cover in parallel.</p>  |
|  | <p>Then tighten the hexagon nuts crosswise with the specified torque of 55 Nm.</p>  |

Grease and slip on the O rings for the air pipe.




Re-attach the servo-valve with cooling tube and the air pipe, check the correct seat of the O rings.



## 8.3 Repair of suction and delivery valves

### 8.3.1 Dismantling

Unscrew the inlet and outlet sockets from the HP head, leave the valves in the HP head.



The inlet and outlet valves are of an identical design.



“Hook” the valves from the HP head with a screwdriver.

Remove the two O rings from the valve body.



Remove the valve seat, spring and ball from the valve body.



### 8.3.2 Assembly

Check the valves for damage and spring ruptures. Replace defective components.



Grease the O rings.



Insert the spring into the valve body.



Place the ball onto the spring.



Place the valve seat onto the ball.

Mount the O rings on either side of the valves.



Insert the valves into the HP head. Make sure that the white valve seat points in the following directions: Inlet valve – outwards, Outlet valve - inwards.



Screw the inlet and outlet sockets into the HP head and tighten the sockets with 120 Nm.






## 8.4 Spool valve

### 8.4.1 Dismantling

|   |  |
|---|--|
|    | <p>Loosen the socket head screws in the spool valve housing.</p>   |
|   | <p>The air pipes are only loosely pushed in and can smoothly be withdrawn from the spool valve housing and the intermediate cover.</p>                   |
|  | <p>Remove the O rings that seal the top cover.</p>   |
|  | <p>Dismantle the locking ring at the spool valve housing with suitable locking ring pliers. (The ring is located opposite the compressed air inlet).</p> |



Use a mandrel to force out the spool valve sleeve with light strokes of the spool valve housing.  
Caution: Make sure to avoid damaging the servo-spool.  
Preferably use a plastic or wooden mandrel.

The O rings on the spool valve sleeve are statically sealing, i.e. they are not subject to wear and tear. This means that the spool valve sleeve has only to be dismantled when it is damaged. Use a mandrel to force the spool valve sleeve out of the spool valve housing.

Caution: Make sure to avoid damaging the spool valve sleeve. Preferably use a plastic or wooden mandrel with an appropriate diameter.



Remove the O rings from the spool and and, if applicable, from the spool valve sleeve.





Remove the O ring from the sealing cap.

### 8.4.2 Assembly

Check all components for damage and replace them as required. There must not be any scoring at the spool valve sleeve.



Grease all O rings.



Slip the O rings onto the servo-valve, sealing cap and, if applicable, the spool valve sleeve.




Grease the spool valve sleeve well, even when it is still installed. Insert the spool with rotating motions into the spool valve sleeve.



If applicable, grease the spool valve housing internally and install the spool valve sleeve with slight rotating motions into the spool valve housing.



Re-insert the sealing cap into the spool valve housing and fasten it with the locking ring.





Use a small quantity of grease to “glue” the O rings for the sealing between spool valve housing and top cover into the O ring nests.



Re-attach the spool onto the DLE. During the process, guide the air pipes into the spool valve housing.



Place the 4 socket head screws to fasten the spool valve housing and tighten the screws with 5 Nm.